

Diagram Key:

Purple: Auxiliary/PTO Port
Blue: Work Port A
Green: Work Port B
Red: Supply
Orange: Exhaust



1204 AIR PROTECTION VALVE

AIR RESERVOIR




Pull Yellow Sleeve to Disengage PTO

Push Red Button and Pull Yellow Sleeve to Engage PTO


Move Lever to Lower Hoist

Move Lever to Raise Hoist

1229 AIR CONTROL VALVE




#1 - FLASHER INPUT
#2 - 12V GROUND
#3 - 12V INPUT




DIS-PTO-A

PTO AIR SHIFTER



POWER TAKE OFF (PTO)



HYDRAULIC PUMP

3116 AIR SHIFT CYLINDER

NOTE:
DEL- PTO AIR INTERLOCK SYSTEM IS TO NOTIFY THE DRIVER NOT TO LEAVE THE P.T.O. ON.

THIS DWG. IS THE PROPERTY AND COPYRIGHT OF DEL HYDRAULICS INC. AND MAY NOT BE REPRODUCED BY ANY MEANS UNLESS WITH THE EXPRESSED PERMISSION OF DEL HYDRAULICS.

DEL Est. 1945 Pneumatic Control Solutions
DEL HYDRAULICS INC.
MADE in the U.S.A.

REV.	DESCRIPTION	DATE
	REVISION HISTORY	

DEL- PTO INTERLOCK AIR SYSTEM UTILIZING THE VEHICLE FOUR WAY HAZARD FLASHER

SHEET: 1 OF 1

GEN. TOL:
.XXX ± .005
.XX ± .01
.X ± .1
GENERAL Ra: N/A µIN
GEN. CONCENTRICITY: N/A TIR
CORNERS/ EDGES: N/A R/CH
CHKD:
DRWN: O.S. NOV. 10/23
REVD: .

WEIGHT: 0.00 lbm | VOLUME: 0.00 in^3
UNITS: INCHES
MAT'L: SEE COMP. DWG. | MAKE FROM: SEE COMP. DWG. | REV: .